

Following are instructions for cutting an EasySpring Plus spring down for use in a smaller shade.



Take off the damper & screw



Take off the Spring End counter-clockwise



### RollEase Headquarters

200 Harvard Avenue  
Stamford, CT 06902  
Phone: 203-964-1573, 800-552-5100  
Order Fax: 203-358-5865

### RollEase West

7310 West Roosevelt Street, Ste. 26  
Phoenix, AZ 85043  
Phone: 623-936-5818  
Order Fax: 623-936-5294

[www.rollease.com](http://www.rollease.com)



Cut the spring.  
Record the cutting length.



Cut the inner tube same length as spring cutting length.



Assemble the Spring End clock-wise.

### RollEase Headquarters

200 Harvard Avenue  
Stamford, CT 06902  
Phone: 203-964-1573, 800-552-5100  
Order Fax: 203-358-5865

### RollEase West

7310 West Roosevelt Street, Ste. 26  
Phoenix, AZ 85043  
Phone: 623-936-5818  
Order Fax: 623-936-5294

[www.rollease.com](http://www.rollease.com)



Drill a hole in the end of tube.

3mm - 1.1x120mm spring

5mm - other spring



Screw & done.

### RollEase Headquarters

200 Harvard Avenue  
Stamford, CT 06902  
Phone: 203-964-1573, 800-552-5100  
Order Fax: 203-358-5865

### RollEase West

7310 West Roosevelt Street, Ste. 26  
Phoenix, AZ 85043  
Phone: 623-936-5818  
Order Fax: 623-936-5294

[www.rollease.com](http://www.rollease.com)