



Balance with ease

Easy Spring Air

Introducing Easy Spring Air, a chain free child-safe roller shade. Effortlessly raise or lower the bottom rail to the desired position.

The premium minimalist design of the Easy Spring Air has eliminated the need for chains or wand devices.





Easy Spring Air

Easily set top or bottom limits and adjust without having to remove the system. The innovative single-stop limiter protects against over-extending the shade.

Operate hard to reach shades using the telescopic pull stick, perfect for overcoming accessibility challenges and tall window installations.

Color Range



White



**Patented
Technology**