SKYLINE EASY-LINK ASSEMBLY MANUAL

June 2019



CONTENTS

June 2019

This manual is to be read in conjunction with the Product Specifications manual

SECTION NO. DESCRIPTION	PAGE NO.
SECTION 1 – TOOLS AND ADDITIONAL ITEMS REQUIRED	1.1
SECTION 2 – SYSTEM DETAILS	2.1
PART A – OVERVIEW	2.1
PART B – DEDUCTIONS	2.2
PART C – BOM & CUTTING LIST	2.2
SECTION 3 ASSEMBLY	3.3
PART A – ASSEMBLING TUBE	3.3
PART B – PREPARE & PACK ASSEMBLIES READY FOR TRANSPORTATION & INSTALLATION	3.5

DISCLAIMER

INTRODUCTION

This product specifications manual has been produced by Rollease Acmeda to supply the necessary information for safe and correct assembly and installation of this system.

DISCLAIMER

Rollease Acmeda has used reasonable care in preparing the information included in this document, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Rollease Acmeda assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Rollease Acmeda reserves the right to make changes without further notice to any products to improve reliability, function or design.

COPYRIGHT

COPYRIGHT © ROLLEASE ACMEDA 2019

All rights reserved. No part of this document may be reproduced or utilised in any means, by any means, electronic or mechanical including photocopying, recordings, or by any information storage or retrieval system, without the express permission from Rollease Acmeda.

SECTION 1 - TOOLS AND ADDITIONAL ITEMS REQUIRED

TOOLS REQUIRED

- Saw
- Drill
- Drill Bits
- Screw Driver Phillips Head, Flat Head
- Scissors
- Measuring Tape
- Pencil

ADDITIONAL ITEMS REQUIRED (NOT SUPPLIED)

To assemble a SKYLINE EASY-LINK, the following non-stocked items are required:


Fabric



SECTION 2 - SYSTEM DETAILS

PART A – OVERVIEW


SKYLINE EASY-LINK




- 3. Medium Easy-Link Intermediate Female Drive
- 4. Medium Multi-Link Bracket Disk & Bearing

SKYLINE EASY-LINK | DUAL CONTROL

The Rollease Acmeda Skyline Easy-Link[™] system combined with the Pin to Pin Disk allows for multiple controls to be used on a single installation allowing for maximum user customisation.









KYLIN	IE EAS	Y-LINK					
			PART NUMBER	DESCRIPTION	U.O.M	QTY	DEDUCTION
		BRACKETS	RB41-0321-XXX138	Medium Link Skyline Bracket Narrow 38mm	Piece		
	EASY-LINK OPTIONS		RB41-0321-XXX050	Medium Link Skyline Bracket Narrow 50mm	Piece		
			RB41-0332-XXX060	Medium Link Skyline Bracket Double V Slim	Piece	n	
SKYLINE			RB41-0331-XXX075	Medium Link Fascia Bracket	Piece		
S	NSY-LI		RB41-0502-XXX000	Medium Easy-Link Bracket Disk + Bearing	Piece		
	EA		RB41-0503-XXX000	Medium Link Bracket Disk Pin to Pin	Piece		
		DRIVES	RB41-1001-XXX038	Medium Easy-Link Intermediate Male Drive	Set	1 x N	
			RB41-1002-XXX038	Medium Easy-Link Intermediate Female Drive	Set	1 x N	




SECTION 3 ASSEMBLY


PART A – ASSEMBLING TUBE











PART B - PREPARE & PACK ASSEMBLIES READY FOR TRANSPORTATION & INSTALLATION



