## **Regulatory Compliance**









Do not dispose of in general waste. Please recycle batteries and damaged electrical products appropriately.

## Specifications:

Model	AUTOMATE   ACML Q10
Model #	MTACQ45-10-M
Voltage	110-120
Torque	10.0Nm
Max Run Time	4 min
Speed	21 RPM
IP Rating	IP44
Limit Switch Type	Mechanical
Amps	1.61A
Temp Working	32°F to 140°F (0°C to 60°C)
Insulation Class	Ш

Rollease Acmeda declares this equipment is in compliance with the essential requirements and other relevant provisions of the following directives:

2014/35/EU	The Low Voltage Directive
2014/35/20	The Low Voltage Directive
2014/30/EU	The Electromagnetic Compatibility Directive
2014/53/EC	R&TTE Directive
UL 1004-1:2012	Rotating Electrical Machines – General Requirements
UL 1004-3:2015	Thermally Protected Motors
CSA C22.2#100	Motors and Generators
CSA C22.2#77	Motors with Inherent Overheating Protection
2011/65/EU	RoHS Directive

## Statement Regarding FCC Compliance

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

## Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which Can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

